

SHUTTER

1. Window Panels, and Shutters

- A. Position the product on the wall in the final location to test for fit.
- B. Apply PL Premium adhesive to perimeter and center areas of the product.
- C. Position the product back on the wall and screw through the face of the product and into the wall behind. Use the appropriate plated screws for the wall material. i.e. Wood or masonry. Note: It may be necessary to install fasteners in the center area of the product to properly secure.
- D. Finish the installation by filling the screw holes, caulking (see "Finishing" section on page 233) around the perimeter if necessary, and prime and paint as desired.

1 • 8 0 0 • 6 8 5 • 9 9 8 1

